



Fig. 4

The seven jumpers are indicated on the parts placement guide by line segments. C12 mounts behind the front panel and not on the board. Pay particular attention to the orientation of the semiconductors. Q5 and Q6 are cemented face-to-face, and R8 mounts over the pair lengthwise, in close contact.

